


INSTALLATION INSTRUCTIONS FOR QUADRANT AND OFFSET QUADRANT



■ You will need



A1		X14
A2		X14
A3	 ST4X10	X6
C	 ST4X30	X16
C1		X8
D		X4
F		X4

J		X2
K1		X1
K2		X1

A1:CHROME SCREW COVER CAP

A2:SCREW WASHER

A3:PROFILE SCREW

C:FRAME ASSEMBLY SCREW

C1:WALL PLUG


D:TOP ROLLER

F:BOTTOM ROLLER

J:DOOR HANDLE

K1:TOP PROFILE COVER

K2:TOP PROFILE COVER



1:WALL PROFILE

2:PROFILE FRAME FOR GLASS

3:TOP AND BOTTOM PROFILE

4:FIXED GLASS PANEL

5:CURVED GLASS DOOR


6:MAGNETIC SEALS


7:FIXED GLASS SEAL


8:DOOR SEAL


9:PROFILE FRAME SEAL



A1
X8
A2
X8
C
X8
C1
X8



A
A
1
1
40mm
40mm
Φ6mm
C1
C



C
X8
3
2
C
3
2
2
3
3
2
4
4
4
3
2
4
8
3
4
7



20mm
20mm
1
2
1
2


A1
X6
A2
X6
A3
X6


A2
A3
A1
Φ3mm


D
X4
F
X4
5
6
5
8
5
8
8
D
5
6
5
5
F
5


5


K1
X1
K2
X1
J
X2
J
K1
K2
24